

Micro Working Distance Camera

Model Name: INS-LXM-1148-10GM Series

Change History			
Rev.	Date	Author	Specification
V1.0	Jun. 2024	INSNEX	Original

Contact Us

If you have any doubts or suggestions during the use of the software, please contact us promptly:

Insnex Technologies Co.,Ltd

Address: Building R, No. 218 Xingming Street, Suzhou Industrial Park, Suzhou Area, China

(Jiangsu) Pilot Free Trade Zone

Postal Code: 215000

Website: http://www.insnex.com/

Telephone: (86) 0512-67159489

E-mail: Services@Insnex.com

INSNEX 2024 1 all rights reserved



1. Product Outline

		1			
Item	INS-LXM-1148	INS-LXM-1148	INS-LXM-1148-10	INS-LXM-1148	Note
Ttom:	-10GM-9M	-10GM-18L	GM-18L-WD30	-10GM-18M	11010
Digital Data					
Output	10GigE*4	10GigE*4	10GigE*4	10GigE*7	
Interface					
Command					
transmission	Serial interface	Serial interface	Serial interface	Serial interface	
interface					
Scanning width	1148	1148	1148	1148	mm
Resolution	900	1800	1800	1800	DPI
Effective pixel	41000	02000	02000	02000	D: 1
point	41000	82000	82000	82000	Pixels
Line frequency	80	40	40	80	kHz
Scanning speed	4.4	0.5	0.5	1.1	m/s
Power supply	+24V×6A	+24V×6A	+24V×6A	+24V×11A	To control
					boards
	12477 64 1247	12477.64		10477	To LED
	+24V×6A	+24V×6A	+24V×6A	+24V×6A	boards
Focus					
position(from	15	15	30	15	mm
glass surface)					
Image format	Mono8	Mono8	Mono8	Mono8	
Appearance	Black	Black	Black	Black	
Colour	Diack	Diack	DIACK	Diack	



2. Serial Interface

This serial interface uses hex code.

Item	Value
Baud rate	115200
Start bit	1
Data bit	8
Parity bit	None
Stop bit	1
Flow control	None

3. Maximum Rating

Item	Symbol	Specification	Note
DC supply voltage	Control boards	+24V±1V	
	LED boards	+24V±1V	
Ambient temperature	Т-	0~+40°C	Operating
	Та	-20~60°C	Storage
Ambient humidity		10%~90%RH	

4. Connector Plug/Unplug

Unplug & plug the cable number should be less than 50. The connector will be ineffective if it is extracted and inserted over that number.

INSNEX 2024 3 all rights reserved



5. Stable Operation

(1) The connector pins should not be touched by bare hands or electrostatic charge materials.

(2) Latch-up

When the supply voltage exceeds the absolute maximum, Latch-up will occur. Latch-up will cause the sensor to be broken, even if the voltage is caused by a surge. If the current varies rapidly in the external circuit, or when the power is switched on and off very frequently, ensure that the voltage of each terminal does not exceed the values indicated in below.

(3) Absolute maximum rating

14	Specification		Unit
Item	Min.	Max.	
Control boards supply voltage	-0.3	+25.0	
LED boards supply voltage	-0.3	+25.0	
Shaft encoder input voltage	-0.3	5.5	V
External trigger input voltage	-0.3	25	
External trigger output voltage	-0.3	25	

6. Reliability

Please operate Micro Working Distance Camera under INS operating conditions, which is specified in section 6.

INSNEX 2024 4 all rights reserved